

## **USER MANUAL**





# **LABOMAT 140B**

**Ride-on Scrubber Dryer With Battery** 

This Guide provides necessary instructions on machine operation and maintenance.

Before operation or use of this machine, please carefully read and understand this Guide.

When ordering the replacement parts, please refer to the spare and accessory parts manual attached to the machine.

Before matching parts or accessories, please firstly determine your machine model and serial number. You can order parts and accessories from any authorized service center or dealer by telephone or mail. This machine can provide excellent service. If the following can be

further done, the optimum efficiency can be obtained with the lowest cost:

- Carefully operate the machine.
- Maintain the machine according to the maintenance instructions provided in the operation manual.
- Use the OE or same-grade parts for maintenance.



#### Protect the environment

Please dispose the old machine components such as packaging material, battery, etc. and toxic liquid such as anti-freezing agent and oil according to your local regulations on waste disposal and on the premise of maintaining the environmental safety. Please ensure to carry out the recycling well.



#### **INDEX**

| Precautions                       | 14 |
|-----------------------------------|----|
| Instructions on machine operation | 15 |
| Machine installation              | 17 |
| Machine unpackaging               | 17 |
| Battery installation              | 17 |
| Machine cleaning method           | 17 |
| Brush/scouring pad                | 17 |
| Machine operation                 | 19 |
| Clean and dirty water tank        | 20 |
| Battery charging                  | 20 |
| Machine maintenance               | 21 |
| Troubleshooting                   | 22 |
| Technical parameters              | 23 |

#### EN

#### **PRECAUTIONS**

This machine is suitable for industrial and commercial use and specially used for cleaning indoor hard floor instead of other purposes.

Please use the suggested scouring pad and brush as well as the commercially available floor cleaner suitable for this machine.

All operators must read, understand and observe the following safety precautions.

The following are explanation for safety warning signs and [for safety] headlines used in this Guide:

Warning: for warning of risks possibly causing personnel injury or death or unsafe operations.

For safety: point out matters which must be observed when using the machine to guarantee safety.

If the following warnings are not observed, it may cause: personnel injury, electric shock, fire or explosion.

#### Warning: fire or explosion hazard:

- -Do not use flammable liquid; do not operate the machine close to or in the place where there is flammable liquid, air or dust.
- -This machine is not equipped with explosion-proof motor. If this machine is used in the place where there is flammable air, liquid or dust, electric motor may generate spark during the start and operation, which may cause flash fire or explosion.
- Please do not pick up flammable materials or reactive metals.
- The battery releases hydrogen. Please be away from spark or open fire. The battery cabin must be kept open when charging.

Warning: Electric shock hazard. Please firstly disconnect the battery wring before maintaining the machine.

Warning: Operation of rotary brush. Do not get close with hands. Please turn off the power before maintaining the machine.

The following information explains the conditions causing potential dangers to the operators or equipment:

#### EN

## **SAFETY RULES**

#### WARNING: Please read this guide before using the machine.

- Please read the labels on the machine very well. Cover the labels in no way and please change it if it has been damaged.
- This machine can be used only by people who are qualified.
- Please keep away this machine from your children and be careful while using this machine at the places which are close to people and children.
- Never blende varied types detergents. Otherwise, it can generate some hazardous gases.
- Place this machine backwards or on its side in no way.
- · Never use this machine at places that have risk to explose.
- Never use this machine for transporting anything.
- Do not use acid solution, otherwise you can damage to people or the machine.
- Please do not operate the machine so long time while it is static. It can damage the place.
- Please do not vacuum something such as razor blade, nail and explosive materials (gasoline, alcohol etc..)
- · This machine is not suitable for cleaning dangerous dust.
- Please use an extinguisher including dust instead of water in the event of fire.
- · Please do not crash shelfs if the things have risk to fall.
- Please determine operating speed according to vacuum conditions.
- · Please avoid to operate this machine at the uneven and dusty places.
- This machine has to arrange washing and drying processes at the same time. So you should use coution signs as considering safety rules while the
  machine is operating at wet ground.
- Please ensure that poor maintenance doesn't causes to that problem if you it would be lived some problem while the machine is operating. And after that, please call to the closest EDİT ENDÜSTRİYEL service center.
- · Please ask original spare parts for LABOORY-LABOOMAT from authorized agent or dealer if you need to change them.
- Please use only original LABOORY-LABOOMAT brushes.
- Please ensure that machine is not operating during maintenance process.
- Please arrange the wirings to the previous state after every maintenance processes.
- · Never take down protective parts which are needed equipment to be taken down.
- Never clean this machine as using pressure water, fountain or corrosive matter directly.
- · Please do not fill up detergent solution hours before using the machine.
- Please provide to be placed all covers at the way it is shown on guide.
- · Please ensure that dust bag is empty before you take dust bag.
- Please do not operate this machine under rain to avoid accidents and motor to burn.
- This machine is not designed for (including children) physically handicapped, deaf, mentally handicapped and not-authorized people. That's kind of
  people should be guarded by responsible person for their safety if they need to use this machine.

#### 1. Please do not operate the machine:

- When contacting flammable liquid or getting close to flammable air, otherwise it may cause explosion or flash fire.
- · Unless being trained and authorized to operate the machine.
- · Unless having read and understood the operation manual.
- . Unless in the conditions of correct operation.

#### 2. Before starting the machine:

Please ensure that all safety equipment have been in place and operated correctly.

## 3. When using the machine:

- · Please walk slowly when encountering the slope and sliding surface.
- · Please wear anti-skid shoes.
- · Please slow down when turning.
- · Report immediately when the machine is broken or the operation fails.
- . Do not let the children play on or around the machine.
- · Observe the mixing ratio and processing instructions on the chemical vessel.

#### 4. Before leaving or maintaining the machine:


- . Stop and place the machine on the stable ground.
- · Shut down the machine.

#### 5. When repairing the machine:

- Avoid moving the parts. Please do not wear loose jacket, shirt or oversleeve.
- · Before operating the machine, please firstly disconnect the battery wiring.
- When treating battery or battery wiring, please wear protective gloves and eye protectors.
- · Avoid contacting battery liquid acid.
- Please do not spray this machine with high pressure or flush this machine with water pipe.
- · Use the replacement parts provided or recognized by the manufacturer.
- All maintenance must be carried out by qualified maintenance personnel.
- · Please do not revise the original design of the machine.

#### 6. When transporting the machine:

- · Please shut down the machine.
- Please do not transport the machine with the battery on.
- Please transport the machine with the aid of the others.
- · Please use the suggested handling apron when handling the machine from the truck or trailer.
- . Use the rope to fix the machine on the truck or trailer.
- Lower the brush head to the lower position.



#### EN

#### Machine Unpackaging

- 1. Please carefully check whether there is damage on the packing box of the machine. If there is, please immediately reflect to the carrier.
- 2. Check the freight list, if there is any omission, please contact the distributor.

#### Freight content:

- Four 6V batteries standard configuration
- · One 24V battery charger standard configuration
- One set of battery cable standard configuration
- One water-absorbing adhesive tape standard configuration
- · Two scrubbing brush standard configuration
- Two dial standard configuration
- · Other accessories additionally purchased
- 3. Before unpackaging the machine, please dismantle the cargo fixed parts and ropes fixing the machine on the warehouse. Carefully unload the machine from the warehouse with the aid of the others.

**Note:** If no handling apron is used, please do not push the machine directly so as to avoid machine damage.


**Note:** To avoid machine damage, please install the battery after unloading the machine from the warehouse.

#### **Battery Installation**

**Warning:** fire or explosion hazard. The battery releases hydrogen. Please be away from spark or open fire. The battery cover must be kept open when charging.

**For safety:** Please wear protective gloves and eye protectors when treating the battery and battery wiring when repairing the machine. Avoid contacting the battery liquid acid.

- 1. Stop and place the machine on the level ground and take out the key.
- Lift up the waste water tank to expose the touchable battery cabin.
- Carefully install the battery in the battery cabin and connect the battery cable according to the following figure



Note: Please do not throw the battery into the battery cabin so as to avoid the damage to the battery and the machine.

Before connecting the battery, please firstly ensure whether the electrodes and electric terminals are clean. Use electrode cleaning fluid and wire brush as required.

Explanation: Paint a thin layer of metal-free lubricating oil or protective spray on the connected wiring to avoid battery corrosion.

5. After the battery is installed, please check the scale of the battery coulombmeter. Charge the battery as required.

### Machine Cleaning Method

Cleaning method:

Manually control the water valve to adjust the volume of the cleaning liquid (water and detergent) flowing to the ground. The brush cleans the floor with the solution mixing detergent and water. While the machine advances, absorb the waste water on the floor with squeegee into the waste water tank.

## Information on Brush and Scouring Pad

To ensure the optimum efficiency, please use the correct type of brush for cleaning. The brush and scouring pad suggested for use are as follows:

- Soft nylon brush (white) It is suggested to clean the coated floor without damaging the floor. Clean without scratches.
- Polishing pad (white) It is used for maintaining highly smooth or polished floor.
- Crash pad (red) It is used for scrubbing slight dirt without damaging the floor.
- Pressure pad (black) It is used for powerfully removing the heavy coating or base or super-powerful scrubbing.

#### Machine Installation

#### Installation and Connection of Squeegee Component

- 1. Stop and place the machine on the level ground and take out the key.
- 2. Lower the lifting rod of the squeegee to the lower position.
- 3. Install the squeegee to the squeegee installation bracket as shown in the figure. Ensure to fully place the fastening knob into the jack and then tighten the knob.
- 4. Connect the vacuum suction pipe to the squeegee component.
- 5. Examine the squeegee adhesive tape and reasonably adjust.

#### Installation of Brush/Scouring Pad

**Explanation:** As for the brush and scouring pad suggested for use, please refer to the section of [Information on Brush and Scouring Pad] in this Guide or consult your local authorized dealer.

- 1. Stop and place the machine on the level ground and take out the key.
- 2. Step on the brush head lifting pedal to lift up the brush head from the ground.
- 3. Place the scouring pad on the holder and then install the drive disc. Fasten the central lock to fix the scouring pad.
- 4. Align the holder/brush installation stud at the motor drive disc buckle and press the motor switch of the brush.
- 5. If the holder and brush are to be dismantled, step on the brush head lifting pedal to lift up the brush head from the ground, press the motor switch of the brush.

#### **Machine Operation**

For safety: Please do not operate this machine before reading and undertanding the operation manual.

Warning: fire or explosion hazard. Do not operate the machine close to or in the place where there is flammable liquid, air or dust.

#### Pre-operational Examination

- · Clean the dust on the ground.
- · Check the scale of the battery coulombmeter. (refer to the battery coulombmeter)
- · Check the abrasion conditions of the scouring pad/brush.
- · Cehck the abrasion conditions of the squeegee adhesive tape and reasonably adjust the angle.
- Confirm that the waste water tank is blank and has been equipped with clean floating filter screen.
- Check the abrasion conditions of the skirt section of the brush head.

#### Machine Operation

- 1. Switch the key of the main power supply to the position of (1).
- 2. Pull down the squeegee lifting rod to lower the squeegee component to the ground.
- 3. Step on the brush head lifting pedal to lower the brush head to the ground.
- 4. Switch on the clean water control knob.
- 5. Press the motor switch of the brush and press the switch of water suction motor.
- 6. Motor drive model: adjust the speed control knob to the cleaning speed required by you.

**Explanation:** It is suggested to use the cleaning speed of 45-60 meters/min.

#### Machine Operation Duration

Warning: fire or explosion hazard. Please do not pick up flammable materials or reactive metals.

- 1. Each cleaning path overlaps by 5cm.
- 2. Let the machine advance constantly to avoid ground damage.
- 3. If there is drag mark on the ground after the squeegee absorbs water, remove the waste with duster cloth wiping adhesive tape. Clean in advance to prevent drag mark.
- 4. Do not operate the machine on the slope with a slope over 5% (3°).
- 5. If there is too much foam, it is suggested to pour the used defoamer solution into the waste water tank.

Note: Do not let the foam enter the filter screen so as to avoid damage to vacuum motor. The foam will make the switch of the filter screen invalid.

- 6. Use double cleaning method to clean the extremely dirty area. Lift up the squeegee firstly for cleaning, sink with solution for 3-5 min, lower the squeegee for re-cleaning.
- 7. Replace or rotate the scouring pad as required.
- 8. Observe the power consumption of the battery coulombmeter (refer to the battery coulombmeter).
- 9. Observe the residual liquid amount through the liquidometer of the clean water tank. In traditional scrubbing method, the consumption for each 10 min is about 10l.
- 10. When the solution in the clean water tank is used up, empty the waste water tank firstly, then re-pour the solution.
- 11. When the staff leaves the machine, stop and place the machine on the level ground and take out the key.
- 12. After cleaning, carry out daily maintenance procedure.

#### **Battery Coulombmeter**

The battery coulombmeter will display the power quantity of the battery. When the battery is full of power, all indicator lights will be on. Along with the consumption of the power quantity, the indicator lights will go out from the right to the left. To prolong the life of the battery, do not let the indicator lights go out to below the following power consumption.

**Explanation:** To prolong the life of the battery, please ensure to charge the battery after the total use time of the machine exceeds 30min.

#### Drainage of Water Tank

After each use, the waste water tank shall be drained and cleaned. The clean water tank shall be periodically cleaned to remove any corroded parts.

Carry the machine to the drainage place, switch off the key of the power supply, and drain the water according to the following drainage instructions:

for safety: pleasestop and place the machine on the level ground and shut down the machine and take out the key before leaving or maintaining the machine.

### Drainage of Waste Water Tank

- 1. Unscrew the drain pipe cover of the waste water tank counterclockwise and take it down.
- 2. Open the cover of the waste water tank and flush the water tank.
- 3. Dismantle and flush the floating filter screen in the waste water tank.

#### **Battery Charging**

**Note:** To prolong the life of the battery and ensure the optimum efficiency of the machine, the battery must be charged after the use time of the machine exceeds

30min. Please do not let the battery exist in the uncharged state for long.

The following charging instructions are suitable for the charger attached to this machine.

Please ensure to use the charger of the following specification to avoid battery damage.

## The specification of the battery charger:

Charger type: - charger for aluminic acid battery. / Output voltage - 24V / Output current - 15A / APO circuit / Suitable for deep cycle battery charging

1. Move the machine to the place with good ventilation for charging.

**Warning:** fire or explosion hazard. The battery releases hydrogen. Please be away from spark or open fire. The battery cabin must be kept open when charging.

- 2. Stop and place the machine on the level ground and turn the key to the close position.
- 3. Before charging, check the electrolyte level in each battery unit.

For safety: Please wear protective gloves and eye protectors when treating the battery and battery wiring when repairing the machine. Avoid contacting the battery liquid acid.

- 4. When charging, please open the side of the waste water tank to facilitate ventilation.
- 5. Plug the AC (alternating current) power cord of the charger to the power socket with sound grounding.
- 6. Plug the DC (direct current) power cord of the charger to the battery charging socket behind the waste water tank.
- 7. The charger will automatically start charging and will automatically swtich off when it is full.

**Explanation:** The machine will not work when being connected to the charger. Note: during the charging of the charger, please do not pull the DC cord of the charger out of the socket of the machine to avoid generation of arc strike.

If the charging must be suspended during the charging, please pull out the AC power cord firstly.

**Warning:** fire or explosion hazard. The battery releases hydrogen. Please be away from spark or open fire. The battery cabin must be kept open when charging.

8. After the charging is completed, recheck the electrolyte level.

#### Machine Maintenance

Only by indeed following daily, weekly and monthly maintenance procedure can the machine be kept in the optimum working state.

Warning: Electric shock hazard. Please firstly disconnect the battery wring before maintaining the machine.

#### Daily Maintenance (after each use)

- 1. Drain and clean the waste water tank
- 2. Dismantle and flush the floating filter screen in the waste water tank
- 3. Drain the clean water tank and flush the water tank with hot water of no higher than 60°C as required
- 4. Dismantle the scouring pad/brush for cleaning. If there is any abrasion, overturn or replace the scouring pad
- Wipe the squeegee adhesive tape. Place the squeegee component in the rising position to avoid damage to adhesive tape.
- 6. Check the abrasion conditions of the scraper edge of the squeegee adhesive tape. If there is any wear and tear, exchange two sides of the adhesive tape.
- 7. Use multi-purpose detergent and wet cloth to wipe the machine.

#### For safety:

please do not spray this machine with high pressure or flush this machine with water pipe when cleaning the machine to avoid failure of electronic component.

- 8. Check the abrasion conditions of the skirt side of the brush head and replace it if there is any wear and tear or damage.
- 9. Charge the battery. To prolong the life of the battery and ensure the optimum efficiency of the machine, the battery must be charged after the use time of the machine exceeds 30min.

#### Monthly Maintenance (every 80 hours)

- 1. Dismantle the filter of the clean water tank from the bottom of the machine and clean the filter screen. Ensure the clean water tank is emptied before dismantling the filter.
- 2. Clean the top of the battery to prevent electrode corrosion (refer to [Battery Maintenance]).
- 3. Check whether the battery wiring is loose.
- 4. Check and clean the cover seal of the waste water tank and replace it if there is any damage.
- 5. Spray the silica gel dry lubricant on all pivots and wheels, and cover a layer of water-proof lubricating oil to ensure smooth operation of wheels and pivots.
- 6. Check whether the nuts and bolts on the machine are loose.
- 7. Check whether the machine leaks.

#### Quarterly Maintenance

Examine the abrasion conditions of the carbon brush of drive motor (drive model), vacuum motor and brush motor every 250 hours. When the abrasionlength of the carbon brush is within 10mm, the carbon brush needs to be replaced. If it is required to deliver the machine for maintenance, please contact with the authorized service center.

**Warning:** Electric shock hazard. Please firstly disconnect the battery wring before maintaining the machine.

## **Machine Transport**

When transporting the machine with truck or trailer, please ensure to following the following binding procedure:

- 1. Lift up the brush head to the transport position
- 2. Use the suggested handling apron to load and unload the machine.
- 3. Lean the front of the machine closely against the front part of the truck or trailer. When the machine is placed properly, lower down the brush head and turn the key to the close position.
- 4. Place blocks behind each driving wheel to prevent the machine from sliding.
- 5. Use the rope to fix the top of the machine to prevent titling. You must install bracket on the sweeping board of the truck or trailer.

**For safety**: when transporting the machine, please use the suggested handling apron when handling the machine from the truck or trailer and use the rope to fix the machine on the sweeping board.

#### Machine Storage

- 1. Please charge the battery before storage. Do not store the battery with the power running out.
- 2. Drain and flush thoroughly the bottom of teh water tank.
- 3. Store the machine in a dry palce and the brush head shall be kept in the rising position.
- 4. Open the cover of the waste water tank. Note: Don not let the machine subject to the rain and store it indoor.
- 5. If the machine is stored in a cold environment, please indeed drain all liquid in the machine.

#### TROUBLESHOOTING

| PROBLEM                              | REASON   | SOLUTION   |  |
|--------------------------------------|--|--|--|
|                                      | The battery has no power                                       | CHARGE THE BATTERY                                 |  |
|                                      | The battery fails  | REPLACE THE BATTERY                                |  |
| The machine can not be operated      | The battery wiring is loose                                    | FASTEN THE BATTERY WIRING                          |  |
|                                      | The main fuse blows out  | REPLACE THE FUSE                                   |  |
|                                      | The brush head rises up from the ground                        | LOWER DOWN THE BRUSH HEAD                          |  |
|                                      | The battery coulombmeter is locked and not started             | CHARGE THE BATTERY                                 |  |
| The brush motor does not work        | The breaker of the brush motor circuit triggers blackout       | RESET THE BUTTON OF THE BREAKER OF THE BRUSH CIRCU |  |
|                                      | The brush (upper/lower) switch fails                           | PLEASE CONTACT WITH THE SERVICE CENTER             |  |
|                                      | The carbon brush of the motor wears                            | PLEASE CONTACT WITH THE SERVICE CENTER             |  |
|                                      | The squeegee rises up from the ground                          | LOWER DOWN THE SQUEEGEE                            |  |
| The vacuum motor does not work       | The fuse of the vacuum motor blows out                         | REPLACE THE FUSE                                   |  |
| The vacuum motor does not work       | The vacuum motor or wiring fails                               | PLEASE CONTACT WITH THE SERVICE CENTER             |  |
|                                      | The carbon brush of the motor is worn                          | PLEASE CONTACT WITH THE SERVICE CENTER             |  |
|                                      | The filter or solution pipe of the clean water tank is blocked | CLEAN THE FILTER OF THE CLEAN WATER TANK           |  |
| A little or no water flows out       | The speed of the flow control knob is set too low              | ADJUST THE WATER CONTROL KNOB                      |  |
|                                      | The screw of the control knob is loosened                      | LUBRICATE THE KNOB AND THEN FASTEN THE SCREW       |  |
|                                      | The waste water tank is full                                   | DRAIN THE WASTE WATER TANK                         |  |
|                                      | The water-absorbing adhesive tape is worn                      | REPLACE THE WATER-ABSORBING ADHESIVE TAPE          |  |
| The waste water recovery rate is low | The water suction pipe is blocked                              | REMOVE THE BLOCKED SCRAPS                          |  |
|                                      | The sealing strip of the waste water tank is damaged           | REPLACE THE SEALING STRIPE                         |  |
|                                      | The vacuum motor fails   | PLEASE CONTACT WITH THE SERVICE CENTER             |  |
| The manifest time charten-           | The battery has flaws  | REPLACE THE BATTERY                                |  |
| The running time shortens            | The battery charging fails                                     | REPAIR OR REPLACE THE CHARGER                      |  |

| Technical parameters      | Unit | Value           |
|---------------------------|------|-----------------|
| Operating voltage         | V/AH | 24 /200         |
| Brush motor               | w    | 550 x 2         |
| Suction motor             | w    | 550             |
| Squeegee lifting motor    | W    | 100             |
| Brush lifting motor       | w    | 100             |
| Drive motor               | w    | 500             |
| Total power               | w    | 2500            |
| Cleaning width            | mm   | 860             |
| Squeegee width            | mm   | 1080            |
| Cleaning efficiency       | m²/h | 5500            |
| Clean water tank capacity | L    | 130             |
| Waste water tank capacity | L    | 140             |
| Machine weight            | kg   | 323             |
| Machine dimension         | cm   | 165 x 108 x 130 |

## **LABOMAT 140B**

| BATTERY        | 24 V / 200 Ah | VACUUM MOTOR | 550 W     |
|----------------|---------------|--------------|-----------|
| BRUSH ROTATING | 180 rpm       | BRUSH MOTOR  | 550 W x 2 |



#### IMPORTER:

AFC MAKINE SANAYI VE TICARET LIMITED SIRKETI

Karakaş mahallesi, Zincirlikuyu 2. Geçidi Sokak No; 9/1. Kırklareli / Merkez Tel: +90 539 116 0139



# www.afcmachine.com

AFC MAKINE SANAYI VE TICARET LIMITED SIRKETI Karakaş mahallesi, Zincirlikuyu 2. Geçidi Sokak No; 9/1 Kırklareli / Merkez

